



Monstrum Tactical 2x32 Scope

S232P

MONSTRUMTACTICAL.COM

The **Monstrum Tactical S232P** is a compact, high performance prism scope suitable for hunting, target shooting, or tactical use. The scope comes equipped with:

- Fixed 2 times magnification with a 32mm objective lens, for targeting out to 200 yards and beyond
- A glass prism optical system, rather than a refracting lens system like traditional scopes, allowing for better optical quality in a much smaller package
- A black glass-etched reticle visible with or without battery powered illumination
- Adjustable reticle illumination with 5 brightness levels in both red and green, allowing for better reticle visibility at night or in low light environments
- ½ MOA/click windage and elevation adjustments
- Aircraft grade 6061 aluminum construction, for lightweight and durable performance
- Sealed, nitrogen charged scope tube for resistance to fog and water



Mounting the Scope:

1. Determine the proper eye relief for positioning the scope. Using the scope's adjustable magnification ring, set the scope to maximum magnification and look through the scope. The optimum eye relief is the farthest distance away from the scope from which you can still see the entire circular field of view. For the S232P, the eye relief should be approximately 4 inches.

2. Set your scope mount and position your scope. Hold your rifle in a comfortable shooting position with your cheek welded to the stock. The scope should be mounted at a comfortable eye relief in relation to this position. Set your scope mount and position the scope accordingly.

3. Secure the scope. Tighten the mounting bolts securely. If necessary, apply a drop of loc-tite® to the threads of the screws to secure them.

Focusing the Scope

The first step in focusing your scope, is adjusting the focus ring at the near end of the eyepiece. Please note that adjusting the focus ring does not bring the target image into focus. Adjusting the focus ring only focuses the eye on the reticle.

To adjust the focus ring:

1. With the scope pointed toward a blank wall or toward the sky, look through the scope.
2. Adjust the focus ring until the reticle is in sharp focus.


Sighting in your scope

Tip:
Before firing any rounds, we recommend bore sighting your rifle. Bore sighting refers to the process of aligning the bore of your rifle with your target, commonly done with a laser bore sighter, and then sighting in your optic accordingly. Bore sighting ahead of time will save you a significant amount of time and ammo, however, bore sighting alone is not enough to properly sight in your rifle. Once bore sighted, you are ready to sight in your scope.

To sight in your scope:

1. Position your target 100 yards away (or at whatever distance you wish to sight your scope at).
2. Position your rifle on a steady shooting platform such as a gun rest or bipod pointed at the target.
3. For variable magnification scopes, set your scope to the maximum magnification.
4. Fire one round at the center of the target, taking care not to change the position of the rifle.
5. Using a spotting scope or binoculars, identify the bullet hole on the target.
6. Using the windage and elevation adjustment dials on your scope, adjust the position of the crosshairs to align with the bullet hole. The elevation dial is located on top of the scope, while the windage dial is located on the right of the scope. Each click of the adjustment dial will move the position of the crosshairs by ½ MOA or roughly ½ inch at 100 yards.
7. Once the crosshairs are aligned with the bullet hole, aim again at the center of the target and repeat the process until you are consistently hitting the center of the target.

S232P Reticle Design



OPERATING THE SCOPE

Reticle Illumination

The S232P is equipped with an illuminated reticle that lights in both red and green in varying brightness intensities. The illuminated reticle aids visibility in low light environments.

The illuminated reticle is powered by a single CR2032 3V battery, located within the reticle illumination dial. To change the battery, use a coin to unscrew the cap of the battery hatch and position the battery negative side down.

S232P Reticle

The S232P includes a clean and functional reticle design allowing for a clear, unobstructed sight picture while still enabled for making simple rangefinding calculations. The reticle is 24 MOA in width or approximately 24 inches in width at 100 yards away. Please note that 1 MOA (Minute of Angle) = approximately 1 inch at 100 yards away.

Warranty Support

Monstrum Tactical ensures strict standards of quality control and provides a one year warranty with all of our rifle scope products. Please note, that to qualify for warranty support, scopes must be purchased new and include proof of purchase. For warranty support, please contact Monstrum Tactical at support@monstrumtactical.com.